

TECHNICAL DATA

Fluke RPM80 Inductive Pick-Up/External Trigger



Product overview: Fluke RPM80 Inductive Pick-Up/External Trigger

Provides RPM readings.

Ordering information



Fluke RPM80

Fluke RPM80 Inductive Pick-Up/External Trigger

Fluke. *Keeping your world up and running.®*

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853

In Europe/M-East/Africa +31 (0)40 267 5100

In Canada (800)-36-FLUKE

From other countries +1 (425) 446-5500

Fluke Electronics (Malaysia) Sdn Bhd

Suite D-3A-4, Block D

SouthGage Commercial Centre, No2

Jalan Dua Off Jln Chan Sow Lin

55200 KL

Malaysia

Email: info.asean@fluke.com

www.fluke.com/my

©2025 Fluke Corporation. Specifications subject to change without notice.

12/2025

Modification of this document is not permitted without written permission from Fluke Corporation.